

## 1. SD card format

- 
- ① Push to open.
- ② Slide in the direction of the arrow on the battery cover.
- ③ Battery cover will open downward.
- ④ SD card is inserted in a slot by direction of a figure.

- THIS CARD HAS  
NOT BEEN INITIALIZED.  
**CANCEL**      FORMAT

- SURE ?
- CANCEL** YES


- NOW FORMATING...
- ▶▶▶▶▶▶▶▶▶▶

- FORMAT COMPLETED.
- YES**


- YES

- T14sgUpdate.exe ... File copy utility
- T14sgUpdate.dat ... Information file for T14sgUpdate.exe
- T14SG\_UPDATE.dat ... Identified file of T14SG
- T14SG\_TS.bin ... Update file of T14SG (piece 3)
- T14SG\_AP.bin ... Update file of T14SG (piece 2)
- T14SG\_UPLD.bin ... Update file of T14SG (piece 1)


2. Please attach the SD card formatted to the card reader of PC.
3. Please run "T14sgUpdate.exe".
4. Please select the drive that attached the SD card. Click the "OK" button.



5. Please select the drive that attached the SD card. Click the "OK" button.




6. Update files is copied to SD card, the following screens are displayed. Click "END" button.



### 3. Update software of T14SG

1. Please insert the SD card which includes the update file.
2. Push the **HOME/EXIT** button.
3. Keep pushing the **HOME/EXIT** button and turn on the power switch.



4. The following screen is displayed after a few second.

PROGRAM UPDATE  
START : PUSH MON . 3SEC

5. Please push the **U.MENU/MON.** button for three seconds, a software update is begun.

PROGRAM UPDATE  
UP LOADING



6. When update is completed, the following screen is displayed. Please turn off power switch.

PROGRAM UPDATE  
COMPLETED



7. Please detach SD card.

8. Please check the software version at INFO in SYSTEM menu.

SYSTEM MENU	
TRAINER	START SEL.
DISPLAY	AUTO LOCK
USER NAME	INFO
SOUND	SBUS SERVO
H/W SET	

INFO	
PRODUCT	012050002
RF ID	122920001
LANGUAGE	ENGLISH
VERSION	1.5
AREA	JAPAN
CARD SIZE	8/3766

# T14SG Software Update Changes (Version 1.5)

This software update modifies features found on the 14SG. If you have questions about these updated directions, please consult your instruction manual or futaba-rc.com for further details. Refer to the original manual where applicable but replace the steps indicated below with these instructions.

## 1. TELEMETRY: VARIO

The melody function can be turned on and off with the specified switch.

\*The melody function plays a different electronic melody when rising and diving.

\*To take advantage of this feature, a Futaba Telemetry Sensor (such as SBS-01A, SBS-01G, VARIO-F1712, VARIO-F1672 or GPS-F1672, sold separately) must be installed.

Melody function switch display. When the cursor is moved to this option and the RTN button is pushed, the display changes to the switch selection screen.

VARIO		2/2
↓ALERT	INH	
↓THRESHOLD		0m/s
↓VIBES	OFF	
MELODY	ACT	SH on

When the melody function is active, "on" is displayed. When the melody function is set to INH or the switch is OFF, nothing is displayed.

## 2. TELEMETRY: DISTANCE

Position information (latitude and longitude) is displayed.

\*Requires an SBS-01G or GPS-F1762 Telemetry Sensor (sold separately).

DISTANCE		3/3
MODE	SURFACE	
POSITION	N 35° 24.7170 E 140° 19.5487	

Current position display.  
N: North latitude, E: East longitude

## 3. TELEMETRY: EXT VOLTAGE

An alarm sounds when input voltage and the EXT voltage alarm are both set to 0V.

\*In the past, when the input voltage was 0V, the alarm stopped.

\*The receiver must have an Extra Voltage port, or a sensor (SBS-01V) sold separately or an EXT battery must be wired.

EXT-VOLT		
<MIN/MAX>	7.4V	7.5V
	7.4V	7.5V
↓ALERT	ACT	
↓THRESHOLD		0.0V
↓VIBES	OFF	

An alarm is activated, even when the input voltage is 0V (when set to 0V).

## 4. TELEMETRY: CURRENT, VOLTAGE, CAPACITY

Compatible with the ROBBE current sensor (F1678). The current, voltage and battery capacity can be displayed. Please read the current sensor instruction manual for more information.

(Example of registration at slot No. 16)

TELEMETRY		Til 2/2
16 CURRENT	16 CAPACITY	
+3.4A	+130mAh	
CURR-1678	CURR-1678	
16 VOLTAGE		
7.2V		
CURR-1678		

CURRENT		1/2
<MIN/MAX>	+4.9A	
	+0.0A	+4.9A
↓ALERT	INH	
↓THRESHOLD	+100.0A	
↓VIBES	OFF	

VOLTAGE		1/2
<MIN/MAX>	7.2V	
	7.2V	7.5V
↓ALERT	INH	
↓THRESHOLD	50.0V	
↓VIBES	OFF	

CAPACITY	1/2
<MIN/MAX>	+80mAh
	+76mAh +80mAh
↑ALERT	INH
↑THRESHOLD	+10,000mAh
↑vibes	OFF

Sensor	The required number of slots	The number which can be used as a start slot	Selling area
CURR-F1678	3 slots	1,2,3,4,5,8,9,10,11,12,13,16,17,18,19,20,21,24,25,26,27,28,29	Europe

## 5. GOVERNOR MIXING (Corresponding model: helicopter)

This function transmits a reference signal from the transmitter for setting the governor side speed display. The governor and transmitter set values (speed display) can be matched.

\*The CAL button can only be displayed in rpm mode.

In "ON", "CAL" appears

GOVERNOR	NORMAL	
COND	NORMAL	ON
MODE	1000-2000rpm	CAL
RATE	1500	<1500rpm>
FINE TUNING		
--	+0 rpm	+0 rpm

Button added to the reference signal output screen. (Displayed only in the rpm mode.)

- ① Move the cursor to the CAL button and touch the RTN button.

GOVERNOR	NORMAL
COND	NORMAL ON
MODE	1000-2000rpm CAL
RATE	1500 <1500rpm>
FINE TUNING	
--	+0 rpm(+0rpm)

- ② The display switches to the screen that transmits the reference signal.

GOVERNOR
rpm CALIBRATION
OFF
MODE 1000-2000rpm

- ③ Move the cursor to OFF and touch the RTN button.

GOVERNOR
rpm CALIBRATION
OFF
MODE 1000-2000rpm

- ④ Once it scrolls to the mode of your choice, touch the RTN button.

GOVERNOR
rpm CALIBRATION
1500 rpm
MODE 1000-2000rpm

- ⑤ Set the transmitter's displayed speed. Adjust the governor's speed display on its side. (Refer to your governor's instruction manual on how to make proper adjustments).

## 6. Fault corrections

- ① Incorrect model condition naming from 8FG model data has been corrected.
- ② Operating failures which may have occurred when the logic and condition switches had identical settings have been corrected.